



# DMLS / SLM Metal 3D Printing.

An introductory design guide for our 3d printing in metal service.

v2.3 - 14th March 2016



# Pricing considerations.

## **Part Volume.**

One of the biggest factors in the price for DMLS \ SLM 3D Printing in metal is the volume of the part. Reducing the volume will reduce the price.

## **Part Orientation.**

Parts built 'tall' in the z axis cost more than printing 'flat'. More layers equals a longer build time.


However, using the optimum part orientation gives a big impact on part quality.

*For example, a Tube design would be printed upright for minimum support requirements and best surface finish.*

Minimising support structures through design also reduces post processing time and cost.

# When to use 3D Printed Metal?

If you have a complex design, or need short lead times, 3D Printing in metal is an attractive option. However for simple designs machining is likely to be more cost effective.



# Support Structures.




Optimising the build orientation of your part is critical to get the best build quality and pricing. The correct build orientation helps minimise support structures, reduce the build time, improve surface finish and speed post build machining.

**Support structures are calculated by us and provide 2 functions as your part is built:**  
**Mechanical.**

- Fix the part to the build plate
- Ease separation from the build plate.
- Stabilise overhanging structures.

**Thermal:**

- Reduction of residual stresses
- Minimising \ preventing warping & cracking
- Preventing localised heat build up.



Part on build plate showing support structures.



### **Support Removal.**

Support structures are removed in post processing. Support in hard to reach areas may make support removal hard or impossible.

Surface finish in areas where support has been removed will be rougher than surfaces without support structures.

### **Surface Finish:**

Surface quality after the building process is about Rz35µm- Rz50µm  
As part of the post build finishing this will be optimised to Rz20µm-Rz30µm by hand finishing, shot peening or vibratory grinding.

### **Powder Removal.**

Parts are built in a volume of metal powder. Provision needs to be made to remove powder from internal channels & voids.

### **We calculate and create where to place the support structures.**

However through design you can minimise how many are required.

# Overhangs.


Overhanging sections of your part may need support. Inclination angles of:

Less than  $40^\circ$  will need support structures.

Between  $40^\circ$  and  $60^\circ$  may need support.


Over  $60^\circ$  should not need supporting.

Overhangs, especially  $90^\circ$  should be avoided.




Support structure angles.

Support structures will be added to the base of the part to connect it to the build plate.




Avoid Right angled overhangs.




Optimise the design to avoid support.

## Managing Overhangs.



Support structures can be eliminated from overhanging features with the use of curves or chamfers:




A double curve offers the optimum solution.



Concave or Convex radius sections avoid horizontal faces less than 45 degrees.




A chamfer with an angle greater than 45 degrees is another solution.




Avoid horizontal overhangs.

# Inner Channels & Holes.

The ideal shape for inner channels is influenced by the need to avoid support structures. Tear-Drop shapes are ideal as much they minimise overhang.



'Tear Drop' or small circular channels remove the need for support structures.



Avoid profiles with overhangs.




Over sized holes or unsupported sections can fail.

The internal path for channels should be curving, avoiding the horizontal where possible. Think curved pipe work, with minimum horizontal paths.

## Holes. Post Build Drilling.

Where holes are required in your design they are printed and can then be drilled as part of the post build processing. Drilling assures that any required holes are round.




Hole diameter less than 4.5mm  
- No support required.




## Inner Channels.

Tear Drop profiles offer the best solution.



Tear Drop shaped profiles for internal channels remove the need for support structures.



Hole diameter over 4.5mm will require support and/or an Optimised and more costly, build orientation.




Example of channels optimised for DMSL / SLM

# Other considerations.



## Large Volume Jumps.


These should be avoided. The expansion and contraction of different volumes or wall thicknesses can cause bulges. This can be managed with build orientation or design changes.



'Bulge' caused by volume jump.

## Wall Thicknesses.

Generally wall thicknesses of  $\geq 0.5\text{mm}$  are possible but is dependent on material and part geometry. Horizontal walls should be  $\geq 1\text{mm}$ .



Where parts taper to a point, the design should be optimised to round off the point.

**Material porosity.** Usually none, air tight when walls are greater than  $0.8\text{mm}$ .

**Material Density.** 99.5% of normal metal.

# Post Build Processing.



## **Additional Services.**

In addition to support removal and shot blasting mentioned earlier in the document we offer a range of post build engineering services including milling & machining, polishing and heat treatments.